



Ultra-GrateLifter®

Operation Instructions



- * Use safe heavy lifting techniques when lifting grates, use your legs and not your back
- * Ultra-GrateLifter lifting capacity is 400 lbs maximum
- * Place safety cones in street when traffic is present and wear safety vests
- * Keep fingers, toes and feet away from grates and other pinch points



1. Position the Ultra-GrateLifter on a stable and level surface adjacent to the grate. Attach the grate hooks in the center of the grate.



2. Lift and remove the grate by carefully applying pressure down on the handle. Make sure that the grate is level and rises evenly above the catch basin.



3. Walk/swing the grate away from the open catch basin and place it safely on the surface.

We give you the calm after the storm™

UltraTech International, Inc. * 11542 Davis Creek Court * Jacksonville, FL 32256
Phone (800) 353-1611 * www.stormwater-products.com