Ultra-DrainGuard® Reusable Model Installation Guide



 Install DrainGuard in catch basin, making sure emptying straps are laid flat, outside the basin and held in place by drain orate



2. Hold down removal flap pockets and emptying straps by covering with soil



3. Properly installed, DrainGuard is out of sight and catches silt without the worry of silt fences or straw bales failing



4. To prepare for emptying DrainGuard, remove soil covering removal flap pockets and insert rebar through pockets



5. Remove catch basin cover grate



6. Remove DrainGuard from catch basin by attaching to both bars and lifting with available equipment



7. Move filled DrainGuard to dumping area and place on the ground



8. Insert a lifting bar through both emptying straps



9. Lift DrainGuard by emptying straps, which are attached to the bottom of the bag. When raised by the straps, bag will turn inside-out and empty



UltraTech International, Inc. 11542 Davis Creek Court Jacksonville, FL 32256 800-353-1611