

## Ultra-Pop-Up Pool, Economy Model Folding Instructions

STEP 1: Decontaminate the Pool and allow to dry. Lay Pool flat on the

ground with the open end facing up.

**STEP 2:** Fold the Pool in half. See Figure 1A. The Pool should be

half of its original size.

**STEP 3:** Fold the Pool in half again. See Figure 1 B.

**STEP 4:** Fold the Pool in half again. See Figure 1 C.

STEP 5: Starting at the longest end, begin to roll the Pool up in as tight a roll

as possible. See Figure 1 D for rolled up Pool view.

STEP 6: Place the Pool into the optional Ultra-Cab Mount Container, optional

Carrying Bag or back into it's original box for storage until required.



Figure 1 A.



Figure 1 B.



Figure 1 C.



Figure 1 D.