

Drum Feed Safety Clamps

Enhance your chemical feed processes with our Safety Clamps

Specifically designed to reduce contamination, our Drum Feed Safety Clamps can be quickly secured onto a 2" NPT or 2" buttress opening on most 15, 30 and 55 gallon plastic drums. The clamps provide a simple way to prevent chemicals from off-gassing into the environment and keep dirt particles from contaminating chemicals. Use in tandem with our serialized Drum Seal Tags & Solid Filter can help with compliance regarding offline storage of chemical drums.

Specifications

- Locks onto a 2" NPT or 2" Buttress Opening
- Fits on 15 – 55 Gallon Plastic Drums
- 4 different filters to choose from: Standard Chemical Filter, Choose-Your-Own Filter with Tear-out Center Rings, Cleaning and Sanitation Filter or Solid Filter
- A variety of colors are available for differentiating chemicals and applications

Benefits

- Easy to use and cost-effective solution to Chemical Feed Problems
- Reduces risk of direct chemical exposure due to "splashing"
- Improves "Indoor Air Quality" (IAQ) - helpful for OSHA inspections
- Reduces contamination of the chemical product by helping to eliminate any dirt, debris, moisture, or environmental hazards from entering the drum
- Aids to reduce cross-contamination by using color-coded Safety Clamps on chemical drums.
- Creates a "greener" work environment, which aids employee's health
- Solid Filter and Drum Seal Tags enable proper Lock out, Tag out procedure for safe storage of chemicals



Drum Lock Safety Starter Kit: Part #CFS-3000

Includes: (1) Clamp (choose model), (1) replacement filter (same model), (1) Spare EPDM plug fitting CFS-1013, (1) spare Silicone plug fitting CFS-1012 & (10) CFS-1014-10pk lock-out tag-out safety tags.

Available Filters

Choose the inner filter design that best fits your application. All filters are resistant to chemicals that can be stored safely in a plastic drum*.



Standard Chemical Filter: Part #CFS-0315

White media makes it easy to determine when to replace the filter. Radial cut design is flexible and allows for use with a range of tubing sizes, from 3/8" to 1".

Default hole size: Approx. 7-8mm



Choose-Your-Size Filter with Tear-Out Rings: Part #CFS-0317

Choose from 4 hole sizes in one filter. For use with 3/8" (OD) feed tubing, 3/8" drum probes, 1/2" drum probes, or 1" flex hose.

Hole options: 8mm, 16mm, 22mm or 30mm



Cleaning & Sanitation Filter: Part #CFS-0316

Special-use filter designed specifically for use with a standard 3/8" drum probe, which has an outer diameter of approx. 16mm

Default hole size: 16mm



Solid Filter: Part #CFS-0318

Prevent contaminants from entering the chemical drum while offline or in storage. Use in conjunction with the Chemical Drum Seal CFS-1014_10pk for help with compliant lock-out, tag-out.

Default hole size: none

*None of our drum clamps are safe for use with chemicals that are only stored in metal drums, such as fuels, hydrocarbons, etc. Such chemicals are generally not safe for use with plastics.