

Ultra-Drain Guard

Oil & Sediment Model, 1-Pack Part# 9376 Part# 9217 / 9356 Ultimate Model, 1-Pack Part# 9218 Oil & Sediment Model, 10-Pack Part# 9377 Ultimate Model, 10-Pack Part# 9393 Oil & Sediment Model, High Capacity, 1-Pack Recycled Model, 1-Pack Part# 9378 Part# 9219 / 9358 Oil & Sediment Plus Model, 1-Pack Part# 9379 Recycled Model, 10-Pack Oil & Sediment Plus Model, 10-Pack Part# 9220

INSTALLATION AND MAINTENANCE INSTRUCTIONS

Installation:

- 1. Remove catch basin grating
- 2. Clean dirt and debris from grating ledge
- 3. Insert Drain Guard. If using the Ultra-Drain Guard High Capacity Model, Part# 9393, Ultra-Drain Guard Retainers must be used see below for installation instructions
- 4. Reinstall grate. To insure maximum effectiveness, Drain Guard skirt should be secured (pinched) between grating and ledge.
- 5. Cut the excess fabric off with a blade or knife if desired.

Installation with optional Ultra-Drain Guard Retainers (Part# 9237 / 9238)

- Follow steps 1 and 2 above. Insert Retainer through handling straps of Drain Guard. (Each Retainer should be holding two straps).
- Insert Drain Guard, placing Retainers across basin opening so that flat plates lay on grating ledge.
- Follow steps 4 and 5 above.

Maintenance and disposal:

- 1. The Ultra-Drain Guard filters are designed to be used for 3 to 6 months under normal conditions. Where heavy contamination is present the unit will have a reduced life expectancy. When the unit has collected about 6 inches of sediment it is recommended that it be replaced. The unit should also be replaced if free oil can be seen floating and is not being absorbed. The Ultra-Drain Guards should be inspected on a regular basis.
- Dispose of unit in accordance with applicable Federal, state and local environmental laws and regulations. The user is solely responsible for compliance with maintenance and disposal laws and regulations. The manufacturer or seller assumes no responsibility for proper or improper maintenance or disposal.
- 3. Part# 9393 (High Capacity model) is equipped with two lifting straps to facilitate in removal of the Ultra-Drain Guard using a forklift or other lifting device, as this model can hold up to 300 lbs. of sediment.

Other Stormwater Management Products are available from UltraTech. Please call us at (800) 353-1611 for a complete catalog or visit us on the web: www.StormwaterProducts.com or for more information on our complete line of environmental containment, spill response, decon and facility protection products. Please visit us on the web: www.SpillContainment.com



9372-9373

Effective Date: 06-24-2010