# **Product Data Sheet**

Item Number: 9606/9607

Item Name: Ultra-SpillPallet P1 Plus

**Load Capacity UDL** 

•800 lbs./each (362.9 kg/each)

## **Sump Capacity**

•62 gal./each (234.7 L/each)

Options Available											
Item #	Size	Color	Misc. Features	Amount	Length	Width	Height	Depth	Int. Dia.	Ext. Dia.	Weight
9607	_	Yellow	With Drain	1 each	40" (101.6cm)	40" (101.6cm)	12" (30.5cm)	_	_	_	55lbs. (24.9kg)
9606	_	Yellow	Without Drain	1 each	40" (101.6cm)	40" (101.6cm)	12" (30.5cm)	_	_	_	55lbs. (24.9kg)

## Description

A poly containment pallet designed with a footprint for storing a single drum.

## **Application**

Used as a containment pallet for a single 55-gallon drum or any other smaller container, to contain any leaks, drips or spills from the stored container.

#### **Product Features**

## Composition

• Sump: Linear, low-density polyethylene with UV inhibitors

• Grate: Injection-molded polyethylene foam

This product helps you comply with:						
Regulatory Citation	Summary					
40 CFR 264.175	Hazardous waste containment systems must be free of structural cracks or gaps, be designed to keep spilled liquids from remaining in contact with the container, prevent run-on and "have sufficient capacity to contain 10% of the volume of the containers, or the volume of the largest container, whichever is greater."					

## **Additional Specifications**

• Fork Pocket Dimensions: 7"W x 4 1/2"H (8" between pockets)

• Grate Deck Area: 26" x 26"

#### **Disclaimers**

**Notice:** Call Technical Services at 1-800-353-1611 or visit our website at SpillContainment.com for chemical compatibility.

