

Product Data Sheet

Item Number: 9610 / 9611

Item Name: Ultra-Spill Pallet P2 Plus

Load Capacity UDL

- 4500 lbs./each (2041.2 kg/each)

Sump Capacity

- 66 gal./each (249.8 L/each)

Options Available											
Item #	Size	Color	Misc. Features	Amount	Length	Width	Height	Depth	Int. Dia.	Ext. Dia.	Weight
9610	—	Yellow	Without Drain	1 each	65.5" (166.4cm)	40" (101.6cm)	8.75" (22.2cm)	—	—	—	80lbs. (36.3kg)
9611	—	Yellow	With Drain	1 each	65.5" (166.4cm)	40" (101.6cm)	8.75" (22.2cm)	—	—	—	80lbs. (36.3kg)

Per Pallet: 10

Description

A low-profile polyethylene sump with deck surface. Used to store and provide containment for up to two 55-gallon drums.

Application

Used to store two 55-gallon drums or other smaller size containers. In the event of a failure of the stored container, liquids are captured in the sump, helping prevent contamination to the surrounding environment.

Product Features

- 4,500 lb. weight capacity — strong enough to support 2 fully loaded 55-gallon plastic drums of liquid
- Low 8.75" profile — drums are easier to load; pumps and funnels are easier to access
- 2-way forklift pockets — makes pallet easy to move, even fully loaded
- Translucent sidewalls permit easy visual inspection
- Removable non-slip grate — adds traction on grate surface; lift out for easy access to sump
- Available with or without drain plug

- 66-gallon sump capacity

Composition

- Sump: Linear, low-density polyethylene with UV inhibitors
- Grate: Injection-molded polyethylene foam

This product helps you comply with:	
Regulatory Citation	Summary
40 CFR 264.175	Hazardous waste containment systems must be free of structural cracks or gaps, be designed to keep spilled liquids from remaining in contact with the container, prevent run-on and "have sufficient capacity to contain 10% of the volume of the containers, or the volume of the largest container, whichever is greater."

Additional Specifications

- Distance Between Fork Pockets: 26"
- Dimensions (Fork Pocket): 7" W x 4 5/8" H
- Capacity: 2 Drums
- Dimensions (Grate): 52" L x 26" W
- Style: Heavy-duty

Disclaimers

- **Notice:** Call Technical Services at 1-800-353-1611 or visit our website at SpillContainment.com for chemical compatibility.

