# **Product Data Sheet**

Item Number: 1000 / 1001

Item Name: Ultra-SpillPallet P4 • deck surface 48" sq.

Load Capacity UDL

•6000 lbs./each (2721.6 kg/each)

### **Sump Capacity**

•66 gal./each (249.8 L/each)

Options Available											
Item #	Size	Color	Misc. Features	Amount	Length	Width	Height	Depth	Int. Dia.	Ext. Dia.	Weight
1000	_	_	No Drain	1 each	53" (134.6cm)	53" (134.6cm)	11.75" (29.8cm)	_	_	_	85lbs. (38.5 kg)
1001	_	_	With Drain	1 each	53" (134.6cm)	53" (134.6cm)	11.75" (29.8cm)	_	_	_	85lbs. (38.5 kg)

Color: Yellow and Black

# Per Pallet: 8

### Description

A 66-gallon polyethylene sump with deck surface with room to store four 55-gallon drums. In the event of a leak, fluid is contained in the sump, preventing contamination to surrounding environment.

#### **Application**

This is the next generation in poly spill pallet design with its low profile and added strength. Typical uses are for waste collection, storage of virgin materials and pumping stations.

#### **Product Features**

- Low 11 ¾" profile makes loading easy
- Made of 100% polyethylene with UV inhibitors stands up to weather and most chemicals
- 4-way forklift entry allows easy access from any direction
- Sturdy poly grates remove for easy cleaning; won't rot like wood
- Ideal for storing extra-heavy drums (weight capacity up to 6,000 lbs. UDL) and has translucent yellow sidewalls for easy leak inspection

- Drain plug in leg allows you to drain sump when necessary (Part# 1001)
- 66-gallon sump capacity; helps you comply with 40 CFR 264.175

## Composition

• Sump: Linear low density polyethylene with UV inhibitors; Grates: Injection molded polyethylene

This product helps you comply with:				
Regulatory Citation	Summary			
40 CFR 264.175	Hazardous waste containment systems must be free of structural cracks or gaps, be designed to keep spilled liquids from remaining in contact with the container, prevent run-on and "have sufficient capacity to contain 10% of the volume of the containers, or the volume of the largest container, whichever is greater."			

## **Additional Specifications**

• Fork Pocket Dimensions: 4"H x 14"W

• Feet Width: 6"

#### **Disclaimers**

 Notice: Call Technical Services at 1-800-353-1611 or visit our website at SpillContainment.com for chemical compatibility.

